4000F Firewall Keypad Instructions

- 1. Make hole in firewall large enough to fit ribbon through.
- 2. Install switch labels to match the first four switches inside the car.
- 3. Velcro mount unit to firewall with connector side up.
- 4. Plug end of ribbon cable connector to blue labeled connector on the unit in car.

Note: The Firewall keypad will only operate the first four switches of your switch panel. Also, the firewall keypad does not light up, however the corresponding switch lights in the car will indicate green or red accordingly.

 Sales: 732-851-5095
 Tech: 774-417-6542

 AutoRod Corporation 21 Le Valley Dr., Englishtown, NJ 07726