




## Model 1401 Switching 12V






 If relay board is not mounted to a grounded surface **DO NOT** connect the red jumper. **Run a lead from the right coil terminal to ground.**

FIGURE 1 SCHEMATIC



**ARC Technical Support**  
774-417-6542 or 732 851-5095

## Switching Ground



**⚡** If relay board is not mounted to a grounded surface **DO NOT** connect the red jumper. **Run a lead from the right coil terminal to ground.**

FIGURE 2 SCHEMATIC

