
Part #1402 Time Delay Relay


WIRING DIAGRAM FOR TIME DELAY RELAY UNIT WHEN USED TO ACTIVATE A DELAYED SECOND STAGE






21 Le Valley Dr. Englishtown, NJ 07726 732-851-5095

Part #1402 Time Delay Relay



#1 if the relay board is NOT mounted to a grounded surface do NOT connect the RED jumper. Run a lead from the terminal marked GROUND J to a grounded surface.

#2 "N O" (Normally Open) Delivers power at end of Timer Cycle "N C" (Normally Closed) loses power at end of Timer cycle



#3 if the relay board is NOT mounted to a grounded surface, This stage activation switch MUST be connected to ground instead of terminal marked "B"